



## DIGITAL TIME SWITCH & CLOCK



# DIGITAL TIME SWITCH & CLOCK



Telectrocuit



**PASS** - PASSWORD  
**PASS** - WRONG PASSWORD  
**0000** - PROGRAM MODE 1 (1 TO 15 PROGRAM/DAY)  
**0001** - EVENT SCHEDULING (1 to 30)  
**0002** - CLOCK SETTING  
**0003** - FACTORY DEFAULT  
**0004** - FACTORY RESET PASSWORD IS 0045

TELECTROCUIT